

O822B	OKI C822CDTN/C822DN/C822N black	44844616
O822C	OKI C822CDTN/C822DN/C822N cyan	44844615
O822M	OKI C822CDTN/C822DN/C822N magenta	44844614
O822Y	OKI C822CDTN/C822DN/C822N yellow	44844613
O831B	OKI C831/841 black	44844508
O831C	OKI C831/841 cyan	44844507
O831M	OKI C831/841 magenta	44844506
O831Y	OKI C831/841 yellow	44844505
O326B	OKI C511/531/M562 black	44973508
R1190T	Ricoh Fax 1190L	431013
R1190D	Ricoh Fax 1190L drum	431008
S5510	Samsung ML 5510/6510	MLT-D309
RAC250B	Ricoh Aficio SP C250DN MPS black	407543
RAC250C	Ricoh Aficio SP C250DN MPS cyan	407544
RAC250M	Ricoh Aficio SP C250DN MPS magenta	407545
RAC250Y	Ricoh Aficio SP C250DN MPS yellow	407546
S2620B	Samsung ProXpress C2620/C2670 black	CLT-K505L
S2620C	Samsung ProXpress C2620/C2671 cyan	CLT-C505L
S2620M	Samsung ProXpress C2620/C2672 magenta	CLT-M505L
S2620Y	Samsung ProXpress C2620/C2673 yellow	CLT-Y505L
SM4530	Samsung ProXpress SL-M4530ND/SL-M4530NX/SL-M4583FX black	MLT-D304S
SM4530X	Samsung ProXpress SL-M4530ND/SL-M4530NX/SL-M4583FX black	MLT-D304L