

Artikel	Benämning	OEM
BD2300	Brother L2300/2340 Drum	DR2300
BT242B	Brother HL 3142 CW, HL 3152 CDW, HL 3172 CDW black	TN-242BK
BT242Y	Brother HL 3142 CW, HL 3152 CDW, HL 3172 CDW yellow	TN-242Y
KTK5140B	Kyocera Ecosys M6030cdn/P6130cdn black	TK-5140K
KTK5140C	Kyocera Ecosys M6030cdn/P6130cdn cyan	TK-5140C
KTK5140M	Kyocera Ecosys M6030cdn/P6130cdn magenta	TK-5140M
KTK5140Y	Kyocera Ecosys M6030cdn/P6130cdn yellow	TK-5140Y
KTK5150B	Kyocera Ecosys M6035cdn/P6035cdn black	TK-5150K
KTK5150C	Kyocera Ecosys M6035cdn/P6035cdn cyan	TK-5150C
KTK5150M	Kyocera Ecosys M6035cdn/P6035cdn magenta	TK-5150M
KTK5150Y	Kyocera Ecosys M6035cdn/P6035cdn yellow	TK-5150Y
KTK8505B	Kyocera Taskalfa 4550ci/4551ci/5550ci/5551ci black	TK-8505K
KTK8505C	Kyocera Taskalfa 4550ci/4551ci/5550ci/5551ci cyan	TK-8505C
KTK8505M	Kyocera Taskalfa 4550ci/4551ci/5550ci/5551ci magenta	TK-8505M
KTK8505Y	Kyocera Taskalfa 4550ci/4551ci/5550ci/5551ci yellow	TK-8505Y
S5510XX	Samsung ML 5510/6510 black	MLT-D309E